

Corin 8300 INSTALLATION GUIDE

TOOLS REQUIRED	INSTALLATION KIT	ENCLOSURE COMPONENTS																															
	<table border="1"> <tr> <td>A</td> <td>7</td> <td>D1</td> <td>1x</td> </tr> <tr> <td>B</td> <td>10x</td> <td>D2</td> <td>1x</td> </tr> <tr> <td colspan="2">DIN7981 4,2x32</td> <td>RIGHT</td> <td></td> </tr> <tr> <td>C</td> <td>6x</td> <td>LEFT</td> <td>1x</td> </tr> <tr> <td>E</td> <td>2x</td> <td></td> <td>2x</td> </tr> <tr> <td>N1</td> <td>1x</td> <td>N2</td> <td>1x</td> </tr> <tr> <td>P</td> <td>1x</td> <td></td> <td>1x</td> </tr> </table>	A	7	D1	1x	B	10x	D2	1x	DIN7981 4,2x32		RIGHT		C	6x	LEFT	1x	E	2x		2x	N1	1x	N2	1x	P	1x		1x				
A	7	D1	1x																														
B	10x	D2	1x																														
DIN7981 4,2x32		RIGHT																															
C	6x	LEFT	1x																														
E	2x		2x																														
N1	1x	N2	1x																														
P	1x		1x																														

